

MODERN DETAIL

BY
Sarah Jane

Installation Instructions (Brick Or Rendered Wall).

1. Unwrap your print in an appropriate location. Preferably on a soft floor like carpet or a rug.
2. Take the loose MDF plate from within the packaging and set it aside.
3. Using a measuring tape, measure from the ceiling down to the point you want the top edge of the print to finish.
4. Let's say you want the top edge to finish 1200mm from the ceiling, and your print is 800mm high.
5. Measure down 1200mm from the ceiling and then a further 500mm which is the point the bottom edge of the hanging plate will finish.
6. Mark this point using a pencil.
7. Using a 6mm drill bit, drill two holes horizontally into the centre of the loose MDF hanging plate.
8. Place the MDF plate against the wall aligning the bottom edge with the pencil mark.
9. Level the hanging plate using a spirit level.
10. Using a pencil mark the location of the holes onto the wall surface.
11. Remove the plate and drill a 6mm hole into the wall.
12. Install the supplied wall fixings into the holes you have drilled.
13. Place the supplied screws through the holes in the hanging plate and then fix them into the fixings that are now in your wall.
14. Using a screw driver, secure the hanging plate to the wall, checking and adjusting it for level as you go.
15. Once you are happy the hanging plate is securely in place, take the glass print from the packaging.
16. Holding the print with a hand on each side (get a second person to help if necessary) lift the print up above the hanging you installed and slide the print down until the two hanging plates connect.
17. Once the hanging plates have connected release the print and check to ensure it's centred.
18. Move the print from left to right to suit.
19. Stand back and enjoy.

MODERN DETAIL

BY
Sarah Jane

Installation Instructions (Gyprock Wall).

1. Unwrap your print in an appropriate location. Preferably on a soft floor like carpet or a rug.
2. Take the loose MDF plate from within the packaging and set it aside.
3. Using a measuring tape, measure from the ceiling down to the point you want the top edge of the print to finish.
4. Let's say you want the top edge to finish 1200mm from the ceiling, and your print is 800mm high.
5. Measure down 1200mm from the ceiling and then a further 500mm which is the point the bottom edge of the hanging plate will finish.
6. Mark this point using a pencil.
7. Using a 6mm drill bit, drill two holes horizontally into the centre of the loose MDF hanging plate.
8. Place the MDF plate against the wall aligning the bottom edge with the pencil mark.
9. Level the hanging plate using a spirit level.
10. Using a pencil mark the location of the holes onto the wall surface.
11. Remove the plate and drill a 10mm hole into the Gyprock wall.
12. Install the supplied Gyprock wall fixings into the holes you have drilled.
13. Place the supplied screws through the holes in the hanging plate and then fix them into the fixings that are now in your wall.
14. Using a screw driver, secure the hanging plate to the wall, checking and adjusting it for level as you go.
15. Once you are happy the hanging plate is securely in place, take the glass print from the packaging.
16. Holding the print with a hand on each side (get a second person to help if necessary) lift the print up above the hanging you installed and slide the print down until the two hanging plates connect.
17. Once the hanging plates have connected release the print and check to ensure it's centred.
18. Move the print from left to right to suit.
19. Stand back and enjoy.